




Saxophone Fingering																					
C		C	C#/D \flat	D	D \sharp /E \flat		E	F	F \sharp /G \flat		G	G \sharp /A \flat		A	A \sharp /B \flat		B	C	C \sharp		
Fingering Type			Alt 1		Alt 1	Alt 2			Alt 1	Alt 2		Alt 1	Alt 2			Alt 1	Alt 2				
Left Hand	1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○
	2	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○	○	○	○
	3	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○	○	○	○
	4	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	5	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Right Hand	6	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	7	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	8	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	9	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○



High Note Saxophone Fingering											
C		C	C \sharp /D \flat	D	D \sharp /E \flat		E	F	F \sharp /G \flat		G
Fingering Type			Alt 1		Alt 1	Alt 2			Alt 1	Alt 2	
Left Hand	1	○	○	○	○	○	○	○	○	○	○
	2	○	○	○	○	○	○	○	○	○	○
	3	○	○	○	○	○	○	○	○	○	○
	4	○	○	○	○	○	○	○	○	○	○
	5	○	○	○	○	○	○	○	○	○	○
Right Hand	6	●	●	●	●	●	●	○	○	○	○
	7	●	●	●	●	●	○	○	○	○	○
	8	●	●	●	○	○	○	○	○	○	○
	9	●	●	○	○	○	○	○	○	○	○



High Note Chinese Flute Fingering						
E		G	A	B	C	
Fingering Type				Alt 1		
Left Hand	1	○	○	○	○	○
	2	○	○	○	○	○
	3	○	○	○	○	○
	4	○	○	○	○	○
	5	○	○	○	○	○
Right Hand	6	●	●	●	○	○
	7	●	●	●	○	○
	8	●	●	○	○	○
	9	●	○	○	○	○



Chinese Flute Fingering									
E		G	A	B	C	D	E	F	
Fingering Type				Alt 1				Alt 1	
Left Hand	1	●	●	●	●	○	○	○	○
	2	●	●	●	●	○	○	○	○
	3	●	●	●	○	○	○	○	○
	4	○	○	○	○	○	○	○	○
	5	○	○	○	○	○	○	○	○
Right Hand	6	●	●	○	○	○	○	○	○
	7	●	●	○	○	○	○	○	○
	8	●	○	○	○	○	○	○	○
	9	●	○	○	○	○	○	○	○

KEY

- = Pressing
- = Release